



Tikinagan

Instructions

1. First, apply glue into the groove of the baseboard
2. Insert Baseboard strip with holes and protection strip into place
3. After 15 minutes of drying time, lace in body wrap with tying one end then lace in and out till you reach the last hole and tie
4. Put the Lace in

Materials

- Three (3) Laces:
 - One (1) Base Lace
 - One (1) Body Lace
 - One (1) Carrying Lace
 - Cradleboard
 - Baseboard with holes
 - Protection strap
 - Backstrap
 - Body wrap
-